

BRUSH SCREEN CLEANING SYSTEM

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
39	7	F01003001	3	Brush Adjusters-Control Side / Left Hand Side(Includes Parts Below)
	7	F01106101	1	Brush Idler Plate Left Hand
42	7	F01105400	1	Adjustments Handle with Spring
42	7	F82080060	1	Shoulder Bolt for Brush Adjuster
38	7	F01004902	3	Brush Adjusters - Idler Side / Right Hand Side(Includes Parts Below)
	7	F01106104	1	Brush Adjusting Plate Right Hand
43	7	F01106300	1	Idler Arm Support
43	7	F82080060	1	Shoulder Bolt for Brush Adjuster
39	7	F01003002	3	Brush Adjusters-Control Side / Right Hand Side(Includes Parts Below)
**	7	F01106003	1	Brush Idler Plate Right Hand
42	7	F01105400	1	Adjustments Handle with Spring
42	7	F82080060	1	Shoulder Bolt for Brush Adjuster
38	7	F01004901	3	Brush Adjusters - Idler Side / Left Hand Side (Includes Parts Below)
		F01106001	1	Brush Adjusting Plate Left Hand
43	7	F01106300	1	Idler Arm Support
43	7	F82080060	1	Shoulder Bolt for Brush Adjuster
41	9	F01104300	6	One Hole Plate with 1-5/8" Bore
51	9	F11807001	2	Straight Jack Plate
51		Not Available	2	Jack Plates-Three Hole Right Hand Side
**	9	F01000200	12	Rope Sheave Assembly Complete (Includes Below)
46	9	F01401300	1	3" Rope Sheave Only with Bushing
50	9	F01802401	1	Rope Sheave Axle with Hardware
40	9	F01101500	1	Rope Sheave Bracket Only
54 ***		F09501900	3	Brush Carrier Assembly 25" x 46" NOTE: INCLUDES ROLLERS & AXLES BUT NOT BRUSHES
53 ***	10	F09501400	6	Brush Carrier Roller for 1-3/16" Shaft
56	10	F09802401	6	Carrier Roller Axle with Hardware
	10	F10002120	6	49-1/2" Black Course Brushes
	10	F10002110	6	49-1/2" White Course Brushes(Used on Wire Screens Only)
48 ***		F01612102	3	Brush Carrier Shafts 1-3/16" x 64"
55	10	F09800100	3	2 Piece Cable Clamps
		F97700003	60	Wirelon Plastic Coated Steel Cable (In Feet)

NOTE: ON SOME OLDER MACHINES A 18" WIDE BRUSH CARRIER AND 1" SHAFT MIGHT HAVE BEEN USED. PLEASE MEASURE WIDTH OF CARRIER AND

MAIN SHOE ASSEMBLY

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
424	33	F03006706	1	Bottom Shoe Complete with Rockers (Right Hand Discharge)
138	30	F03118601	1	Right Shoe Side
***		F03118602	1	Left Shoe Side
		F03120207	1	Pitman Board 3/4" x 7-1/2" x 57-1/8"
132		F03016510	2	Front Hanger with Block on Both Sides
137		F03102601	2	Shoeside Hanger Support Block
133		F03016520	3	Back Shoe Hanger with Block
432	33	F03101720	2	Wood Sand Spout Track (Cut to Length)
433	33	F03301002	2	Metal Sand Spout Guide
431	33	F08308	1	Sand Spout Left Hand Machines (Check Measurements)
431	33	F08308	1	Sand Spout Right Hand Machines (Check Measurements)
441	33	F0830	1	Second Straw Spout Left Hand Machines (Check Measurements)
441	33	F0830	1	Second Straw Spout Right Hand Machines (Check Measurements)
44	30	F01200203	6	Pinion Gear with 3/4" Bore
45	30	F01200300	6	4" Long Rack
49	30	F01801700	6	Escutcheon Plate
47	30	F01608303	3	Tilting Rod 3/4" X 60-1/2"
52	30	66276400	3	3/4" Hex Nut
192		F03401700	1	Canvas Apron Assembly
145	33	F03500210	2	Top and Middle Rocker Assembly Complete (Parts for Rocker Below)
151	30	F03600200	1	Right Hand Wooden Rocker Arm Only
**	30	F03600300	1	Left Hand Wooden Rocker Arm Only
153	30	F03800413	2	60" Metal Screenway Liner
156	30	F03801100	2	60" Metal Rubber Holding Strip
159	30	F91152006	10.2	Rubber Seal 2-1/2" Wide
		F03801000	2	Screen Stop
144	30	F03500800	2	Screen Hook Assembly
	30	F03800002	2	Bottom Rocker Brace
177	30	F03505800	1	Top Pipe Girt Support
141	30	F03310009	1	Grain Stop Assembly with Rubber
		F90005303	1	Rocker Adjusting Girt
175	30	F03500600	2	Rocker Pivot Cup

MAIN SHOE ASSEMBLY CONTINUED

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
145	33	F03500310	1	Bottom Rocker Assembly Complete (Parts for Rocker Below)
151	30	F03600400	1	Right Hand Wooden Rocker Arm Only
**	30	F03600500	1	Left Hand Wooden Rocker Arm Only
153	30	F03800413	2	60" Metal Screenway Liner
156	30	F03801100	2	60" Metal Rubber Holding Strip
159	30	F91152006	10	Rubber Seal 2-1/2" Wide
		F03806000	2	Screen Stop (New Style)
144	30	F03500800	2	Screen Hook Assembly
	30	F03800002	2	Bottom Rocker Brace
177	30	F03505800	1	Top Pipe Girt Support
141	30	F03310009	1	Grain Stop Assembly with Rubber
		F90005303	1	Rocker Adjusting Girt
175	30	F03500600	2	Rocker Pivot Cup
		F03500500	1	Apron Assembly

Note: Front of the Machine is Where the Screens are Inserted Into the Machine.

Discharge Spouts are Determined by Standing at the Front and Facing the Machine.

Right Hand Discharge Spouts Would Discharge Towards Your Right Hand.

24	24	F01002803	1	Single Belt Idler Assembly Complete 5-1/2" (Includes Below)
178	24	F01100100	1	Idler Pivot Lever
191	24	F01806202	1	5-1/2" Belt Take Up Shaft
179	24	F01103300	1	1" Cast Iron Pillow Block
180	24	F01400700	1	Idler Sheave with Bushing
185	24	F01805010	1	Belt Tightner Axle with Hardware
