

Top Fan Section

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
All	26	Not Available	1	Air Trunk Assembly Complete (Includes Below)
5	3	F01601700	1	Fan Shaft 1-15/16" X 74"
10	3	F92400024	2	1-15/16" Bearing Insert (A-Frame Housing not Available)
18	3	F05502400	2	8" Wide Hide Static Fan Assembly
215	26	F05501202	1	Right Side Top Fan Housing Assembly (Includes 2 Sides & Metal)
215	26	F05501205	1	Left Side Top Fan Housing Assembly(Includes 2 Sides & Metal)
15	1	F05003900	2	Top Fan Bleeder Inlet Slide Assembly
12	1	F04303136	1	Adjusting Handle & Rod 36" Long (Includes Handle With Knob)
**	1	F04001600	1	Hand Crank Handle with wood Knob
4	1	F05313000	2	Adjusting handle shaft Bearing
	1	F01013500	2	Valve Control Assy Complete (Includes Parts Listed Below)
1	1	F01005500	1	Universal Joint
9	1	F01805800	1	6" Threaded Screw Shaft with 5/8" Shank
13	1	F04313500	1	Swivel Plate (bolts to wood side)
	1	F04313100	1	Plain Pivot Nut
14	1	F04314800	1	Swivel Arm Pivot Lever
	1	F04313200	1	Threaded Pivot Nut

TOP AIR DISCHARGE VALVE ASSEMBLY

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
21	ALL	F04500001	1	Complete Valve (8 wide)(Shaft not Included)
20	4	F01614600	1	Top Valve Shaft 1" x 55" (Measure Length)
22	4	F04800002	1	Hinged Gate Weldment 34-3/8"
**		F04600510	1	Gate Board

**		F92700004	2	Gate Springs
23	4	F04501402	1	#8 Discharge Roll Assembly with Flanges (Around 34" Long) Measure Roll Length
25	4	40000038	4	1" Bore Flangette Stampings
186	4	F92460200	2	1" Bearing
NOTE: ASSEMBLY DOES NOT INCLUDE DRIVE SHEAVES OR SHAFT				
BRUSH SCREEN CLEANING SYSTEM				
ITEM	PAGE	PART		
NO.	NO.	NUMBER	QTY.	DESCRIPTION
39	7	F01003001	2	Brush Adjusters-Control Side / Left Hand Side(Includes Parts Below)
	7	F01106101	1	Brush Idler Plate Left Hand
42	7	F01105400	1	Adjustments Handle with Spring
42	7	F82080060	1	Shoulder Bolt for Brush Adjuster
38	7	F01004902	2	Brush Adjusters - Idler Side / Right Hand Side(Includes Parts Below)
	7	F01106104	1	Brush Adjusting Plate Right Hand
43	7	F01106300	1	Idler Arm Support
43	7	F82080060	1	Shoulder Bolt for Brush Adjuster
39	7	F01003002	2	Brush Adjusters-Control Side / Right Hand Side(Includes Parts Below)
**	7	F01106003	1	Brush Idler Plate Right Hand
42	7	F01105400	1	Adjustments Handle with Spring
42	7	F82080060	1	Shoulder Bolt for Brush Adjuster
38	7	F01004901	2	Brush Adjusters - Idler Side / Left Hand Side (Includes Parts Below)
		F01106001	1	Brush Adjusting Plate Left Hand
43	7	F01106300	1	Idler Arm Support
43	7	F82080060	1	Shoulder Bolt for Brush Adjuster
41	9	F01104300	4	One Hole Plate with 1-5/8" Bore
51	9	F11807001	2	Straight Jack Plate
**	9	F01000200	8	Rope Sheave Assembly Complete (Includes Below)
46	9	F01401300	1	3" Rope Sheave Only with Bushing
50	9	F01802401	1	Rope Sheave Axle with Hardware
40	9	F01101500	1	Rope Sheave Bracket Only
54 ***		F09501900	2	Brush Carrier Assembly 25" x 46" NOTE: INCLUDES ROLLERS & AXLES BUT NOT BRUSHES
53 ***	10	F09501400	4	Brush Carrier Roller for 1-3/16" Shaft
56	10	F09802401	4	Carrier Roller Axle with Hardware

****Refers to the previous listing number. May give parts within that assembly, right side-left side numbers, or numbers for parts that are specific to RH or LH machines.**

**Note: Front of the Machine is Where the Screens are Inserted Into the Machine.
 Discharge Spouts are Determined by Standing at the Front and Facing the Machine.
 Right Hand Discharge Spouts Would Discharge Towards Your Right Hand.**

ECCENTRIC SHAFT ASSEMBLY (WITH COUNTER WEIGHTS)

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
85	15A	F01611900	1	Eccentric Shaft 1-1/2" X 78-1/2" (Includes Keys)
89		Not Available	2	6714 Halfmoon Flange Bearing
**		F92400022	1	1-1/2" Bearing Insert Only for Below
89		F92053126	1	6714 Flange Bearing Conversion Kit
89		F92401080	1	1-1/2" Pillow Block Bearing
87	15A	F92441082	1	7475 1-1/2" Halfmoon Bearing Complete w/Bearing
**		F92400026	1	1-1/2" Halfmoon Bearing Insert Only for Above
93	15A	F19701600	1	12" Diameter 1-1/2" Bore Stationary Disc
92	15A	F19701400	1	12" Diameter 1-1/2" Bore Thrust End Disc
94	15A	F19500700	1	1-1/2" Adjusting Nut (Includes Zerk with Plug #24)
88	15A	F92452090	1	B-34 Thrust Bearing
515	15A	F01104600	4	Counterweight Ends
514	15A	F01804405	2	Counterweight 16-1/2"
91	15A	F19503600	2	1-1/2" Throw Eccentric Assembly Complete (Includes Below)
**		F92400053	1	Bearing Insert for Eccentric Assembly
**		F19804004	1	1-1/2" Bore 1/2" Throw Eccentric Hub
**		F19703000	1	Eccentric Housing for Assembly
512	15A	F19602102	1	Pitman Left Side 24" Long
513	15A	F19602101	1	Pitman Right Side 24" Long

****Refers to the previous listing number. May give parts within that assembly, right side-left side numbers, or numbers for parts that are specific to RH or LH machines.**

**Note: Front of the Machine is Where the Screens are Inserted Into the Machine.
Discharge Spouts are Determined by Standing at the Front and Facing the Machine.
Right Hand Discharge Spouts Would Discharge Towards Your Right Hand.**

MAIN SHOE ASSEMBLY

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
424	33	Not Available	1	Bottom Shoe Complete with Rockers / (OLD # F030061--)
138	30	F03116801	1	Right Shoe Side
***		F03116802	1	Left Shoe Side
		F03120207	1	Pitman Board 3/4" x 7-1/2" x 57-1/8"
132		F03016510	2	Front Hanger with Block on Both Sides
137		F03102601	2	Shoeside Hanger Support Block
133		F03016520	3	Back Shoe Hanger with Block
432	33	F03101720	2	Wood Sand Spout Track (Cut to Length)
433	33	F03301002	2	Metal Sand Spout Guide
431	33	F0830-----	1	Sand Spout Left Hand Machines (Give Measurements)
431	33	F0830-----	1	Sand Spout Right Hand Machines (Give Measurements)
441	33	F0830-----	1	Straw Spout Left Hand Machines (Give Measurements)
441	33	F0830-----	1	Straw Spout Right Hand Machines (Give Measurements)
44	30	F01200203	4	Pinion Gear with 3/4" Bore
45	30	F01200300	4	4" Long Rack
49	30	F01801700	4	Escutcheon Plate
47	30	F01608303	2	Tilting Rod 3/4" X 60-1/2"
52	30	66276400	2	3/4" Hex Nut
192		F03401700	1	Canvas Apron Assembly
145	33	F03500210	1	Top Rocker Assembly Complete (Parts for Rocker Below)

151	30	F03600200	1	Right Hand Wooden Rocker Arm Only
**	30	F03600300	1	Left Hand Wooden Rocker Arm Only
153	30	F03800413	2	60" Metal Screenway Liner
156	30	F03801100	2	60" Metal Rubber Holding Strip
159	30	F91152006	10.2	Rubber Seal 2-1/2" Wide
		F03801000	2	Screen Stop
144	30	F03500800	2	Screen Hook Assembly
	30	F03800002	2	Bottom Rocker Brace
177	30	F03505800	1	Top Pipe Girt Support
141	30	F03310009	1	Grain Stop Assembly with Rubber
		F90005303	1	Rocker Adjusting Girt
175	30	F03500600	2	Rocker Pivot Cup

MAIN SHOE ASSEMBLY CONTINUED

ITEM NO.	PAGE NO.	PART NUMBER	QTY.	DESCRIPTION
145	33	F03500310	1	Bottom Rocker Assembly Complete (Parts for Rocker Below)
151	30	F03600400	1	Right Hand Wooden Rocker Arm Only
**	30	F03600500	1	Left Hand Wooden Rocker Arm Only
153	30	F03800413	2	60" Metal Screenway Liner
156	30	F03801100	2	60" Metal Rubber Holding Strip
159	30	F91152006	10	Rubber Seal 2-1/2" Wide
		F03806000	2	Screen Stop (New Style)
144	30	F03500800	2	Screen Hook Assembly
	30	F03800002	2	Bottom Rocker Brace
177	30	F03505800	1	Top Pipe Girt Support
141	30	F03310009	1	Grain Stop Assembly with Rubber
		F90005303	1	Rocker Adjusting Girt
175	30	F03500600	2	Rocker Pivot Cup
		F03500500	1	Apron Assembly

****Refers to the previous listing number. May give parts within that assembly, right side-left side numbers, or numbers for parts that are specific to RH or LH machines.**

Note: Front of the Machine is Where the Screens are Inserted Into the Machine.

Discharge Spouts are Determined by Standing at the Front and Facing the Machine.

Right Hand Discharge Spouts Would Discharge Towards Your Right Hand.

24	24	F01002803	1	Single Belt Idler Assembly Complete 5-1/2" (Includes Below)
178	24	F01100100	1	Idler Pivot Lever
191	24	F01806202	1	5-1/2" Belt Take Up Shaft
179	24	F01103300	1	1" Cast Iron Pillow Block
180	24	F01400700	1	Idler Sheave with Bushing
185	24	F01805010	1	Belt Tightner Axle with Hardware